

Installation Instructions

1. Leave turbidity curtain skirt tied to floats as delivered.
2. Lay out sections end-to-end (Figure 1).



1



3. Attach ends as shown in the Illustration with 1/4 inch nylon rope or heavy-duty zip ties, and the included hooks. (If you have a Type III, there will be another hook in the middle of the skirt.)

4. Secure one end on land.

5. Tow remaining sections out into water (Figure 2).

*Amount of sections towed at one time depends on conditions, experience, amount of workers, equipment, etc.



2

6. Once it is towed into position and anchored in place, release the skirt from the floats (Figure 3 and 4).



3

7. To remove turbidity curtain, raise the skirt and secure before towing to minimize damage. Relocating the curtain without raising the skirt may cause significant damage to the skirt.

*Illustration shown loosely tied to demonstrate connection. During deployment, be sure to tie lace connectors as tightly as possible (1/4 inch nylon rope or heavy-duty zip ties).



4